

## General Guidelines

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- Never modify this product in any way.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measurements when using this product.
- Parts and/or instructions are subject to change without notice.



## Safety

- Before using the Show Rock, ensure other persons are clear of the vehicle and the rock.
- Ensure that the Show Rock is free from damage before use.
- It is recommended to use four-wheel drive vehicles on Show Rocks.
- Do not exceed the rated weight capacity. Show Rocks have a weight capacity of 2,500 lbs. per wheel, equating to a 10,000 lb. vehicle weight capacity.
- Use Show Rocks on a dry, level and hard surface that is clean and clear of debris. Acceptable surfaces include: asphalt, grass, dirt. Do not use if tires are wet.
- Drive slowly and cautiously onto and off of the Show Rock. Never accelerate or brake suddenly.
- Another person, standing clear of the vehicle, should observe and guide the driver when using the Show Rock.
- Do not disconnect brakes, engine, transmission components, drive train, drive shaft, universal joints, or wheels while the vehicle is on the Show Rock.
- Always chock tires that are in contact with the ground upon the vehicle being positioned on the Show Rock.
- Place the vehicle transmission in Park, or the lowest gear for manual transmissions, and engage the parking brake.

## Operations

1. Inspect the Show Rock to make sure they are not damaged.
2. Use Show Rocks on a flat and even surface that is clean and clear of debris. Acceptable surfaces include: asphalt, grass, dirt.
3. If so equipped, place the vehicle in four-wheel drive mode. With a slow and steady approach, use the diagrams below to find the recommended point of entry when mounting the Show Rock.  
NOTE: RR-ROCK-6-FS can be approached on any side.
4. Never accelerate or brake suddenly. It is highly recommended a “spotter” assist the driver while ascending to ensure proper approach and final placement.
5. Upon reaching the vehicle’s resting on the Show Rock, engage the parking brake. It is recommended that a wheel chock be used to prevent the vehicle from rolling off the Show Rock.
6. Inspect the perimeter of the vehicle to ensure the vehicle is secure and stable.
7. In preparation for descending the Show Rock, verify the parking brake is engaged prior to the removal of wheel chocks.
8. Enter the vehicle, apply the brake and start the engine. Upon verifying the vehicle brake is engaged, disengage the parking brake.
9. Place the transmission in the appropriate position and slowly descend the Show Rock in a controlled manner. Another person, standing clear and to the side of the vehicle, should guide the driver.



RR-ROCK-10-RB, RR-ROCK-10-SS



RR-ROCK-17-RB, RR-ROCK-17-SS

## Product Warranty and Liability

Race Ramps purchased from an authorized dealer or directly from Race Ramps LLC are backed by a one-year warranty. Our warranty is strictly limited to the repair or replacement of manufacturer defects and does not cover damage to a car, personal injury, labor, or any other damage or injury. Race Ramps LLC is not responsible for the damage caused by improper or unintended use. In no event shall Race Ramps LLC be responsible for consequential damage or costs. The warranty shall terminate one year from the date of purchase by the original owner and is not transferable. Because we are continuously conducting research and development, specifications are subject to change without notice. Those items sold by Race Ramps LLC, but manufactured by other companies are subject to the manufacturer’s warranty and policy.